SETUP GUIDE - XRS2/XRS2i STICK READER

Transferring animal lifetime information (e.g. EID/VID pairs) to the stick reader

Overview

A file containing animal lifetime information can be transferred to the XRS2 or XRS2i Stick Reader (the stick reader) prior to the scanning session. This will mean that when the animal's EID is scanned, corresponding animal lifetime, or visual identification information will be displayed during scanning.

For example, before a scanning session, you can transfer a file containing animal EIDs and corresponding VID pairs to the stick reader. During the scanning session, when an animal's EID is scanned, the corresponding VID will be displayed in large numbers, making it easier to identify the animal.



-When the EID tag is scanned.

VID/Birth Year is displayed in large numbers.

VID is unique within a Birth Year, so it's useful when scanning animals born in different years to see the VID/Birth Year together to identify the animal.

Steps for transferring animal data to the stick reader

There are two (or three) steps required to transfer animal lifetime information to the stick reader:

- 1. Prepare a file containing animal lifetime information (this may be a tag supplier's bucket file or a file which you have created yourself).
- 2. Transfer the file to the stick reader using Data Link for PC.
- 3. Set up the stick reader to display particular fields during scanning (this step is not necessary if you have transferred EID/VID pairs because EID and VID fields are displayed already by default).

After this, you will be ready to scan animals.

Tru-Test

DATAMARS

DΛΤΛΜΛRS

1 Preparing a file containing animal lifetime information

Using a tag supplier's bucket file

You can transfer a tag supplier's bucket file to the stick reader. A bucket file may need modifying in order to be transferred successfully to the stick reader. See the technical information on the following page for advice on formatting.

Here are two examples:

New Zealand

1	A	В	С	D
1	00000 0 942 000040891822	351110	18	1
2	00000 0 942 000040892138	351110	18	2
3	00000 0 942 000040892151	351110	18	3
4	00000 0 942 000040892332	351110	18	4
5	00000 0 942 000040892572	351110	18	5
6	00000 0 942 000040855614	351110	18	6

Bucket file as supplied.

Column A = EID with prefix

 $Column \ B = NAIT \ number \ as \ printed \ on \ tag.$

 $\label{eq:Column C} {\sf Column \ C} = {\sf Year \ as \ printed \ on \ tag}.$

 $Column \ D = Animal \ number \ as \ printed \ on \ tag.$

1	A	В		
1	EID	LID		
2	942 000040891822	351110-18-1		
3	942 000040892138	351110-18-2		
4	942 000040892151	351110-18-3		
5	942 000040892332	351110-18-4		
6	942 000040892572	351110-18-5		
	a province of the second province of the second province of the second province of the second s			

Bucket file modified, ready for transferring to the stick reader.

A header row has been added in row 1. Field names used match the defaults used on the stick reader (EID, LID). EID column – prefix removed.

LID column – columns B, C and D combined.

Australia

1	A	В		
1	3GMXR227XSN17298	981 123542058219		
2	3GMXR227XSN17299	981 123542058218		
3	3GMXR227XSN17300	981 123542058217		
4	3GMXR227XSN17301	981 123542058216		
5	3GMXR227XSN17302	981 123542058215		
6	3GMXR227XSN17303	981 123542058214		
1				

Bucket file as supplied. Column 1 = NLIS numbers Column 2 = EID numbers.

4	Α	В		
1	LID	EID		
2	3GMXR227XSN17298	981 123542058219		
3	3GMXR227XSN17299	981 123542058218		
4	3GMXR227XSN17300	981 123542058217		
5	3GMXR227XSN17301	981 123542058216		
6	3GMXR227XSN17302	981 123542058215		

Bucket file modified, ready for transferring to the stick reader.

A header row has been added.

Field names used match the defaults used on the stick reader (EID, LID).

ΔΛΤΛΜΛRS

Creating your own file

Alternatively, can create your own file containing animal lifetime information using MS Excel. Alternative methods or software may be used, as long as the resulting file is in .csv, .xls, xlsx or .txt format. See the technical information below for specific advice on formatting.

Here is an example:

À	A	В	С	D
1	EID	VID	Breed	Sex
2	985 152003896570	345	Angus	Steer
3	982 000167397472	12	Angus	Steer
4	982 000168838051	143	Hereford	Steer
5	982 000168838052	16	Hereford	Heifer
6	985 152003896786	103	Angus	Steer
-				



By default, MS Excel will display a long number (e.g. EIDs) in scientific notation (e.g. 9.85152E+15):

	A2 🔻 🖱	f _x	985152	0003896570
4	А	В	С	D
1	EID			
2	9.85152E+15			

This may cause issues when the file is transferred to the stick reader.

To change this, select the column containing EIDs, right-click, select **Format Cells**. In the **Number** tab, select **Number** and set **Decimal Places** to 0.

The EIDs will now display normally:

A2 🔫 (*		L.	<i>f</i> _x 9	9851520003896570		
1	A	В		С	D	
1	EID					
2	9851520003896570					
			-			

Technical information about animal information files

- A header row must be included. Use the same default field names used on the stick reader (EID, VID, Breed, Sex, DOB). You can use any case as long as the field name is spelt correctly (e.g. breed, Breed or BREED is acceptable). If using a field name other than the default field names, the stick reader will create a new field.
- It doesn't matter which order the columns are in.
- All information in the file will be transferred to the stick reader, so if your file contains a column of data which you don't need, you should delete it.
- The file must only contain letters and digits. It cannot contain any of the following characters [](){};,~^\|#".
- EIDs in the alerts file must be in one of these formats: Decimal (e.g. 964 155000012939, Decimal2 (e.g. 964155000012939) or Hexadecimal (e.g.8000F66416B8808B). This is regardless of the EID format setting in the stick reader itself. EIDs with the following formats cannot be included in the alerts file: ISO (e.g. 100000964155000012939) and ISO23 (e.g. A000000964000000123456 animal or R000000964000000123456 non-animal).
- A VID may contain up to 24 characters. If a VID is long (between 16-24 characters), the whole VID will be saved in the session file, but only the last 16 characters will be displayed on the stick reader during scanning. VIDs longer than 24 characters will not be transferred to the stick reader.
- If using a txt file, fields must be separated by a comma (essentially, a .csv file).
- Up to 49,000 life data records can be transferred.

DΛΤΛΜΛRS

Transferring the animal lifetime information file to the stick reader

Transfer the file containing animal lifetime information from the PC to the stick reader using Data Link for PC software.

- 1. Connect the stick reader to a PC using the cable supplied.
- 2. Launch Data Link on your PC.
- 3. Click \clubsuit to transfer data from the PC to the stick reader.
- 4. Select Animal lifetime information and click Next.



Browse to find the file and click **Open**.

Data Link will confirm that the file has been successfully transferred to the stick reader. Click **OK**.



If animal lifetime information already exists on the stick reader, the information will be merged with the existing information.

Enabling fields on the stick reader

Depending on the fields you have chosen to transfer, you may need to change the way that the stick reader is set up so that fields are displayed during scanning.



3

By default, the stick reader will display both EID and VID fields, so if you have transferred EID/VID pairs to the stick reader, this step is unnecessary.

To enable fields on the stick reader:

- 1. Press **O** to turn on the stick reader.
- 2. Press **W** and select **Settings**.
- 3. Select Animal Data.
- 4. Select the fields you want the stick reader to display during scanning.



For further information regarding your stock management system, contact Datamars Ltd on 0800 878 837 (NZ), 1800 621 324 (AU), 800 874 8494 (US), 028 2076 8696 (UK). For technical support, contact 0800 AGDATA (0800 243 282) (NZ), 1800 248 774 (AU), 800 433 3112 (US), 028 2076 8696 (UK).

> © Datamars Limited, 2018-2022. All rights reserved. Issue 3 02/2022



